

BUNN®

BEVERAGE DISPENSING

USE & CARE INSTRUCTIONS for ThermoFresh® SERVER



STEP 1

The Server Cover needs to be removed to fill the Server when brewing from a Bunn-O-Matic® Dual TF DBC or Single TF DBC or ICB coffee brewer.



STEP 2

When proper precautions are followed, 1.0 up to 1.5 gallons of coffee may be brewed directly into the server and then transported to a remote serving location. The server must be placed on a sturdy counter or shelf.



STEP 3

Place a cup or container in center of serving platform as indicated.



STEP 4

Open the faucet handle until the desired quantity is dispensed.

DAILY CLEANING



STEP 1

Run a complete brew cycle of *just hot water* into the server and let it set for a minute. Empty the server completely by opening the faucet.



STEP 2

Remove the drip tray and drip tray cover.



STEP 3

Turn the server upside down. Remove three screws securing the bottom plate to stand. Using a phillips screwdriver with at least a 10" shank, remove three screws attaching the stand to the server.



STEP 4

Remove the lid, fill server with cleaning solution and thoroughly clean the inside of server.

NOTE: Bunn-O-Matic recommends the 3 step method for cleaning and sanitizing the server. The 3 step method consists of hot soapy water using an approved detergent, a fresh water rinse, and an aqueous sanitizing solution using an approved **non-chlorine** sanitizer. **Do not submerge server.**

DAILY CLEANING (Continued)



STEP 5

Rinse server thoroughly using fresh water rinse.



STEP 6

Fully fill server with sanitizing solution for 5 minutes then drain through fully open faucet.



STEP 7

Remove the large plastic cover from the bottom of the server, then remove the clamps and silicone tube from the server.



STEP 8

Remove the faucet handle/stem assembly by unscrewing the faucet nut just beneath the faucet handle.



STEP 9

Remove sight gauge shroud by pulling straight up. Remove sight gauge tube, nut, ferrule and o-ring.



STEP 10

Use enclosed cleaning brush to thoroughly clean the fill tube of the lid assembly, faucet, and sight gauge tube.



STEP 11

Disassemble the faucet/stem assembly. Thoroughly wash all faucet parts, lid, and silicone tube in a mild detergent and water solution. Rinse the parts in hot water. Sanitize the parts for five minutes, then air dry completely.



STEP 12

Reassemble the faucet and attach it, the lid, sight gauge and silicone tube to the dispenser.

Wash the entire outside surface of the server with a clean damp cloth. Do NOT clean this equipment with a water jet device.